

## 1 FROM THE DESK OF THE ROBOTSMITHS

Thank you University of Melbourne for your Husky order! As part of the integration, we have prepared this quick reference memo for you and your team detailing your specific package.

## 2 SAFETY WARNING

Use of an autonomous robot is inherently dangerous. Please take time to locate the Red E-STOP button on the rear of the Husky. The E-STOP and key switch on the rear of the Husky are used to stop the Husky movement, but DO NOT control power to the payloads.

## 3 SYSTEM OPERATIONAL TIPS

For best battery performance and life, it is advised that the batteries be charged immediately after use. If the vehicle begins halting unexpectedly, doing one or more of the following may improve performance:


- Reducing motor power draw by lowering acceleration, turning in place less, or limiting the grade of terrain being traversed.
- Reducing peripheral power draw by unplugging or otherwise shutting off devices which are not in use.

Your Husky's battery can be charged by plugging its terminals into the included charger. Simply match red to red and black to black. A light on the top of the charger will illuminate to indicate charging is taking place. When the charging light turns green, the battery is fully charged!

## 4 GETTING STARTED

Your system has been configured to allow you to get started immediately after receipt. Follow these instructions to get moving:

1. Remove the battery door and connect the battery power cable into the MCU.
2. Turn on the Husky.
3. Release all emergency stop controls on the Husky. The "COMM" light should illuminate green.
4. Use the gamepad to control Husky's motion.



## 5 NETWORK INFORMATION

Parameter	Value
Robot Static IP	192.168.131.1
Robot Hostname	cpr-umb02
Robot Username	administrator
Robot Password	clearpath
Serial Number	a200-0483
ARK IP	192.168.132.111
Front Hokuyo UST10LX IP	192.168.132.21
Rear Hokuyo UST10LX IP	192.168.132.22
SwiftNav IP	192.168.0.222
Access Point Radio IP	192.168.131.51
Access Point Radio Username	admin
Access Point Radio Password	clearpath
Access Point SSID	UMB02 Husky

## 6 COMMUNICATING WITH THE ROBOT

To communicate directly with the robot PC, you can SSH in. It will be necessary to ssh into the robot for tasks such as installing, modifying or removing software and files on the robot. Note that you will not be able to use GUI tools such as rviz over an SSH connection:

```
ssh administrator@192.168.131.1
```

OR

```
ssh administrator@cpr-umb02
```

In order to use rviz and other visualization tools, you must declare the robot as master, and set the user computer IP. In a console on the user pc, type:

```
export ROS_MASTER_URI=http://cpr-umb02:11311
```

You should then be able to view a list of topics published by the robot with:

```
rostopic list
```

It will be necessary to declare the robot as master in every new terminal window, unless you change the master permanently in your ROS environment variables. If you are unable to connect with the robot via its hostname, your computer or network equipment may not be routing hostnames properly. In Ubuntu on your local computer, open your /etc/hosts file:

```
sudo nano /etc/hosts
```

Add the following line immediately below the line that contains 127.0.1.1, substituting in the robot's current wifi IP address. This address may be obtained by connecting directly to the robot via Ethernet, and using the "ifconfig" command. You may want to talk to your system administrator about giving the robot a permanent wifi address to ensure it always connects with the same IP address. The below example shows the setting if wired directly into the robot lan.

```
192.168.131.1      cpr-umb02
```

To ease communications between the robot and your computer, you can also add a similar entry in the robot's computer, pointing at one or more development computers.

## 7 SETTING UP YOUR WORKSPACE

There is a workspace installed in your robot for development and custom packages. You will likely want to be able to use these packages on your local machine. To do this, make a new folder on your local computer:

```
mkdir catkin_ws && cd catkin_ws
```



```
mkdir src && cd src
```

Then copy all of the packages from the robot to your local machine

```
scp -r administrator@cpr-umb02:~/catkin_ws/src/* .  
cd ..
```

Now, make sure you have all of the dependencies needed to build these packages:

```
rosdep install --from-paths src --ignore-src --rosdistro=$ROS_DISTRO -i -y  
catkin_make  
source ~/catkin_ws/devel/setup.bash
```

## 8 GPU

The computer in your robot has been equipped with a Graphics Processing Unit (GPU). Should you need to connect a monitor to the robot computer, make sure it is connected to one of the ports on the GPU. To check whether the GPU is functioning properly, you can use the `nvidia-smi` utility:

```
nvidia-smi
```

The current driver version of your card should be listed in the top row.

## 9 WIRELESS ACCESS POINT

The wireless access point built into your robot is a convenient way to communicate with your robot without requiring a connection to wifi infrastructure in your location. Simply turn on the robot, and connect to the SSID being broadcast by the robot's access point. The SSID and login information are available in the Network Information section of this document.

Once connected to your robot's access point, your computer will be granted an IP address via DHCP. It should now be possible to communicate with the robot's onboard computer and payloads.

Should you need to change any settings on the AP, connect to it as usual via wifi. Then, enter its IP address into a web browser on your computer.

To connect your robot to the internet, plug a live internet connection into the WAN port on the access point. The robot and any connected computers should then be granted access to the internet.

*Some corporate network infrastructures may not permit an unauthorized access point. If this is the case at your location, please contact your IT administrator for assistance with connecting the Base Station to your intranet.*

## 10 ARK CONTROL

Start the ARK Bridge. SSH into the robot, and enter:

```
roslaunch husky_cpr_ark_navigation husky_ark_navigation.launch
```

Check Diagnostics. On your local machine,

```
roslaunch rqt_robot_monitor rqt_robot_monitor
```

Under "Other," the various ARK Bridge topics should display green.

Start ARK. On the robot,

```
rosservice call /ark_bridge/start_autonomy "req_data: {}"
```

The command should complete with the status "ark\_service\_timeout: False". If the status is True, then an error has occurred at some point.

Use the ARK. On your local machine, connected to the same network as the robot, open a Google Chrome browser to:

```
http://192.168.131.1
```

Please see the included ARK Manual for further information on using the ARK interface and its various sub-systems.

**Your computer has been configured with a dedicated Ethernet port for ARK communications. When making changes to your robot or computer, make sure that the ARK remains connected to this port, and the network settings remain unchanged. If you need to make changes to your robot that require modifying this configuration, please contact Clearpath Support.**

## 11 BUMBLEBEE CAMERA

The Bumblebee camera images cannot be viewed via ssh. Declare the robot as ROS Master, then from the command line:

```
roslaunch image_view image_view image:=/camera/left/image_color compressed  
roslaunch image_view image_view image:=/camera/right/image_color compressed
```

The Bumblebee image streams may also be viewed from within rviz by clicking "Add," selecting the "By Topic" tab, then choosing the desired "/image" stream (NOT /camera).

To calibrate your camera, use the camera\_calibration package: [http://wiki.ros.org/camera\\_calibration](http://wiki.ros.org/camera_calibration)

## 12 HOKUYO UTM-10LX

The Hokuyo UTM-10LX is an Ethernet-connected single-beam LIDAR. The data it produces is best viewed from within rviz, but you can check that it is publishing data using the hz command:

```
rostopic hz /front/scan
```

```
rostopic hz /rear/scan
```

The Hokuyo LIDAR data may be easily added to rviz, by navigating to the "Sensing" sub-folder and adding the relevant Hokuyo topic to "LaserScan."

## 13 MICROSTRAIN GX5-25 IMU

The Microstrain IMU publishes filtered data. This imu data may be checked by echoing the following topics:

```
rostopic echo /imu/data
```

## 14 SWIFTNV GPS

The SwiftNav receiver features a number of status LEDs which can be used to tell at a glance the status of the sensor.

Solid Green	Power On
Flashing Yellow	Waiting for GPS Fix
Solid Yellow	GPS Fix Achieved

The SwiftNav GPS publishes to /piksi/navsatfix\_best\_fix. Note that the topic will only publish when a valid GPS fix has been achieved:

```
rostopic echo /piksi/navsatfix_best_fix
```

Additional sensor data from the SwiftNav GPS receiver is available from other topics in the same namespace, such as:

```
rostopic echo /piksi/tracking_state
```

```
rostopic echo /piksi/debug/receiver_state
```



## 15 VISUALIZING IN RVIZ


You can visualize your robot using rviz. To do so, you must first move a copy of any extra customizations from the robot into a workspace on your local computer (See "Setting Up Your Workspace.") Then, source the workspace:

Declare the robot as ROS Master:

```
export ROS_MASTER_URI=http://cpr-umb02:11311
```

Launch rviz:

```
roslaunch husky_viz view_robot.launch
```



You can rotate the model using your cursor, and zoom in or out by scrolling up or down. Strafe by holding down Shift and dragging the model. The robot itself may be driven directly from rviz by changing to interact mode. In this mode, arrows appear around the model. Drag the arrows to make the robot move.

Additional sensor topics may be added to the rviz interface by clicking the "Add" button in the bottom left, selecting "By topic," then choosing the desired topic from the list.

More information on rviz is available here: [wiki.ros.org/rviz](http://wiki.ros.org/rviz)

---

## 16 LEARNING

If you are new to using ROS, please visit our support page for information on how to get started using your new robot: [support.clearpathrobotics.com](http://support.clearpathrobotics.com)

Please contact our support team directly at [support@clearpathrobotics.com](mailto:support@clearpathrobotics.com) if you have any questions that aren't answered on our support page. For ROS-specific questions, we recommend visiting [answers.ros.org](http://answers.ros.org), which we also keep an eye on.

Sincerely,

The Robotsmiths



## 1 SYSTEM

Project	UMB02
Platform	Husky (a200-0483)
Date	Tuesday, October 23, 2018

## 2 NETWORKING TESTS

Status	ID	Target	Notes
PASS	Customer_PingTest	192.168.131.1	Verify IP Address
PASS	VelodyneHDL321_PingTest	192.168.131.20	Verify IP Address
PASS	PCHostname_PingTest	cpr-umb02	Verify IP Address
PASS	HokuyoUST10LX2_PingTest	192.168.132.22	Verify IP Address
PASS	HokuyoUST10LX1_PingTest	192.168.132.21	Verify IP Address
PASS	ARK_PingTest	192.168.132.111	Verify IP Address
PASS	WAP_PingTest	192.168.131.51	Verify IP Address

### 3 TOPIC TESTS

Status	ID	Target	Notes
PASS	VelodyneHDL321_velodyne_points_AdvertiseTest	/velodyne_points	Verify Topic Existence
PASS	VelodyneHDL321_velodyne_points_RateTest	10Hz	Verify Topic Frequency
PASS	MicrostrainGX5_imu_data_AdvertiseTest	/imu/data	Verify Topic Existence
PASS	MicrostrainGX5_imu_data_RateTest	100Hz	Verify Topic Frequency
PASS	HokuyoUST10LX1_frontscan_AdvertiseTest	/front/scan	Verify Topic Existence
PASS	HokuyoUST10LX1_frontscan_RateTest	40Hz	Verify Topic Frequency
PASS	HokuyoUST10LX2_rearscan_AdvertiseTest	/rear/scan	Verify Topic Existence
PASS	HokuyoUST10LX2_rearscan_RateTest	40Hz	Verify Topic Frequency
PASS	SwiftNav_piksi_navsatfix_best_fix_AdvertiseTest	/piksi/navsatfix_best_fix	Verify Topic Existence
PASS	SwiftNav_piksi_navsatfix_best_fix_RateTest	10Hz	Verify Topic Frequency
PASS	PointGreyBumblebee_camera_left_image_colorcompressed_AdvertiseTest	/camera/left/image_color/compressed	Verify Topic Existence
PASS	PointGreyBumblebee_camera_left_image_colorcompressed_RateTest	15Hz	Verify Topic Frequency

2

### 4 MISCELLANEOUS TESTS

Status	ID	Target	Notes
PASS	ROSWTFTTest	N/A	General ROS Test

## 1 VELODYNE HDL32 1

### 1.1 Serial Number



772838281

## 2 MICROSTRAIN GX5

### 2.1 Serial Number



422075581

## 3 HOKUYO UST10LX 1

### 3.1 Serial Number



H1819689

## 4 HOKUYO UST10LX 2

### 4.1 Serial Number



H1819687

## 5 PLATFORM

### 5.1 Serial Number



a200-0483

## 6 SWIFTNV

### 6.1 Rover Serial Number



180864801252

## 7 GPU

### 7.1 Serial Number



1812536251813932

## 8 POINT GREY BUMBLEBEE

### 8.1 Serial Number



17584594

## 9 WAP

### 9.1 Serial Number



0271159610